



Name	Date modified	Type	Size
 450U_High Lift.rfa	11/11/2024 8:54 AM	Autodesk Revit Fa...	3,212 KB
 450U_High Lift.txt	11/11/2024 8:54 AM	Text Document	39 KB
 450U_Low Head Room Door.rfa	11/11/2024 8:54 AM	Autodesk Revit Fa...	3,252 KB
 450U_Low Head Room Door.txt	11/11/2024 8:54 AM	Text Document	39 KB
 450U_Standard_Lift.rfa	11/11/2024 8:54 AM	Autodesk Revit Fa...	3,184 KB
 450U_Standard_Lift.txt	11/11/2024 8:54 AM	Text Document	39 KB
 450U_Vertical Lift Break Away.rfa	11/11/2024 8:54 AM	Autodesk Revit Fa...	3,984 KB
 450U_Vertical Lift Break Away.txt	11/11/2024 8:54 AM	Text Document	39 KB
 450U_Vertical Lift Single Incline.rfa	11/11/2024 8:54 AM	Autodesk Revit Fa...	3,388 KB
 450U_Vertical Lift Single Incline.txt	11/11/2024 8:54 AM	Text Document	39 KB

Save all the files into a single location.



Under the Insert Tab, select the Load Family option.



This will open a new window. Navigate to the location you saved the BIM files and select your door style.

Specify Types

Family: 450U\_Standard\_Lift.rfa


Types:

Type	Width (all)	Height (all)	Panel 1 (all)	Panel 2 (all)	Panel 3 (all)	Panel 4 (all)	Panel 5 (all)	Panel 6 (all)	Panel 7 (all)	
8'-0" x 8'-0"	8' 0"	8' 0"	450U 24in_Panel	450U 24in_Panel	450U 24in_Panel	450U 24in_Panel	450U No_Panel	450U No_Panel	450U No_Panel	450U
8'-0" x 9'-0"	8' 0"	9' 0"	450U 24in_Panel	450U 21in_Panel	450U 21in_Panel	450U 21in_Panel	450U 21in_Panel	450U No_Panel	450U No_Panel	450U
8'-0" x 10'-0"	8' 0"	10' 0"	450U 24in_Panel	450U No_Panel	450U No_Panel	450U				
8'-0" x 12'-0"	8' 0"	12' 0"	450U 24in_Panel	450U No_Panel	450U					
8'-0" x 14'-0"	8' 0"	14' 0"	450U 24in_Panel	450U						
8'-0" x 16'-0"	8' 0"	16' 0"	450U 24in_Panel	450U						
8'-0" x 18'-0"	8' 0"	18' 0"	450U 24in_Panel	450U						
8'-2" x 8'-0"	8' 2"	8' 0"	450U 24in_Panel	450U 24in_Panel	450U 24in_Panel	450U 24in_Panel	450U No_Panel	450U No_Panel	450U No_Panel	450U
8'-2" x 9'-0"	8' 2"	9' 0"	450U 24in_Panel	450U 21in_Panel	450U 21in_Panel	450U 21in_Panel	450U 21in_Panel	450U No_Panel	450U No_Panel	450U
8'-2" x 10'-0"	8' 2"	10' 0"	450U 24in_Panel	450U No_Panel	450U No_Panel	450U				
8'-2" x 12'-0"	8' 2"	12' 0"	450U 24in_Panel	450U No_Panel	450U					
8'-2" x 14'-0"	8' 2"	14' 0"	450U 24in_Panel	450U						
8'-2" x 16'-0"	8' 2"	16' 0"	450U 24in_Panel	450U						
8'-2" x 18'-0"	8' 2"	18' 0"	450U 24in_Panel	450U						
9'-0" x 8'-0"	9' 0"	8' 0"	450U 24in_Panel	450U 24in_Panel	450U 24in_Panel	450U 24in_Panel	450U No_Panel	450U No_Panel	450U No_Panel	450U
9'-0" x 9'-0"	9' 0"	9' 0"	450U 24in_Panel	450U 21in_Panel	450U 21in_Panel	450U 21in_Panel	450U 21in_Panel	450U No_Panel	450U No_Panel	450U
9'-0" x 10'-0"	9' 0"	10' 0"	450U 24in_Panel	450U No_Panel	450U No_Panel	450U				
9'-0" x 12'-0"	9' 0"	12' 0"	450U 24in_Panel	450U No_Panel	450U					
9'-0" x 14'-0"	9' 0"	14' 0"	450U 24in_Panel	450U						
9'-0" x 16'-0"	9' 0"	16' 0"	450U 24in_Panel	450U						
9'-0" x 18'-0"	9' 0"	18' 0"	450U 24in_Panel	450U						
9'-2" x 8'-0"	9' 2"	8' 0"	450U 24in_Panel	450U 24in_Panel	450U 24in_Panel	450U 24in_Panel	450U No_Panel	450U No_Panel	450U No_Panel	450U
8'-9" Hgt	9' 2"	8' 9"	450U 21in_Panel	450U No_Panel	450U No_Panel	450U				


Select one or more types on the right for each family listed on the left

OK Cancel Help


After selecting your style, a new window will appear with various door sizes. Select the size(s) you wish to use. You can hold the CTRL key and select multiple sizes.



Under the Architecture Tab, select the Door option.



Under the Properties you will see the doors you selected. This is where you select the door you want to place in your project.



After the door is placed, you can select it and see the options in the properties. Here you can select things like design options, windows, drum size, etc.